

## Assembly Instruction

ITEM NO.: LT001

IMPORTANT: PLACE ALL PARTS ON A CLEAN AND SMOOTH

SURFACE SUCH AS A RUG OR CARPETTO

AVOID THE PARTS FROM BEING SCRATCHED

MORNOVERDREEMS

KINDLY FOLLOW THE ADDEMBLY

INSTRUCTIONS STEP

DO NOT TIGHTEN ALL SCREWS UNTIL THE BED

IS FULLY SET-UP















