Best Master Furniture™
The Imported Furniture Specialist


ASSEMBLY INSTRUCTION

ITEM#BM2001


NO	PARTS		QTY
A	CABINET		1 PC
B	LEG		4 PCS

NO	HARDWARE		SIZE	QTY
Z01	BOLT		Ø8mm*30mm	8 PCS
Z02	FLAT WASHER		Ø8mm	8 PCS
Z03	SPRING WASHER		Ø8mm	8 PCS
Z04	ALLEN KEY		Ø5mm	1 PC

STEP1



STEP2



Finish

