
Please check whether all parts are available, then assemble by illustration .

TAA	DOG	LIST	٠.
ν_{α}	N.I.		
1 /1	17 1 7 3	1 . 1 . 3 1	

1:Leg-----2PCS

3:Flat Washers8PCS

4:Sprinh Washers 8PCS



ITEM: T1953 SIDEBOARD

ASSEMBLY PROCEDURE

VERY IMPORTANT: Please install the legs by the alphabet designated on each.

1:Place the mirrored Chest upside down on a soft surface.

2:Affix the Legs by aligning pre-drilled holes under with pre-threaded holes in legs

3:Secure each leg by tightening Allen Bolts, Lock Washers and Flat Washers using the Allen Wrench included

