

ASSEMBLY INSTRUCTIONS MODEL: SELENA DINING TABLE

Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched. CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.


- 2) DO NOT OVER-TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.
- 3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

PARTS LIST (FOR 1 NOS. OF TABLE)


NO.	COMPONENT	QTY.
P1	TABLE TOP	1
P2	PEDESTAL LEG	1
Р3	LEG PRONG	4
P4	MOUNTING PLATE	1


HARDWARE LIST (FOR 1 NOS.OF TABLE)


NO.	DESCRIPTION		
H1	WRENCH	C	1
H2	HEX NUT	(o)	8
НЗ	M8 SPRING WASHER	@	8
H4	M8 FLAT WASHER	0	8
H5	JCBC SCREW M6 x 35MM	THE SEC	8
Н6	M6 SPRING WASHER	0	8
H7	M6 FLAT WASHER	(3)	8
H8	ALLEN KEY M4		1



COMPLETE ASSEMBLY









ASSEMBLY INSTRUCTIONS

MODEL: SELENA DINING CHAIR

Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched. CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

2) DO NOT OVER-TIGHTEN BOLTS AND NUTS AS IT MAY DAMAGE THE SCREW RHREAD.


3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

PARTS LIST (FOR 2 COMPLETE CHAIRS)

NO.	COMPONENT	QTY.
PI	CHAIR BACK	2
P2	CHAIR SEAT	2
P3	FRONT LEG	4

HARDWARE LIST (FOR 2 NOS. OF CHAIRS)

NO.	DESCRIPTION-		QTY
HI	JCBC SCREW M6 X 80) mentend	8
H2	JCBC SCREW M6 X 60	 anamaw 	8
Н3	JCBC SCREW M6 X 35	() museum	4
114	SPRING WASHER	(2)	20
H5	FLAT WASHER	(3)	20
Hó	ALLEN KEY	1	ı
H7	NAIL LEG	••••••	8



COMPLETE ASSEMBLY

