







Best Master Furniture™
The Imported Furniture Specialist





Assembly Instruction


T1910: Dining Chair

Parts List

	#1 x 1pc x 2 Seat Cushion
	#2 x 2pcs x 2 Front Leg
	#3 x 1pc x 2 Left Rear Leg
	#4 x 1pc x 2 Right Rear Leg

Hardware List

	#A x 1pc x 2 Allen Wrench M5
	#B x 8pcs x 2 Lock Washer 5/16"
	#C x 8pcs x 2 Flat Washer 5/16"
	#D x 8pcs x 2 Bolt 5/16" x 2-1/2"








#1

#B x 4pcs
#C x 4pcs
#D x 4pcs

1. Prepare 4 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#D) then a flat washer (#C) onto that same bolt (#D).



2. Insert the front legs (#2) into the slots along the front of the seat cushion (#1), then insert the bolt assemblies from within and secure.




#2

#B x 4pcs
#C x 4pcs
#D x 4pcs

2. Insert the rear legs (#3,4) into the slots along the back of the seat cushion (#1), then insert the bolt assemblies from within and secure.

Note: Left and right is determined by facing the front of the chair in its upright position.




1. Prepare 4 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#D) then a flat washer (#C) onto that same bolt (#D).



Best Master Furniture™
The Imported Furniture Specialist

If wobbly, please ensure to level the chair with the flooring, and
adjust the bolts gradually until the chair does not wobble anymore



ASSEMBLY IS COMPLETED