



Best Master Furniture™
The Imported Furniture Specialist






GW122-E ACRYLIC END TABLE

ASSEMBLY INSTRUCTIONS




Pre-assembly

- 1) Please read all instructions carefully and completely before assembly.
- 2) Save all packing materials until assembly is completed to avoid accidentally discarding any parts of hardware.
- 3) Two person assembly required.


Parts List:

A	B	C	D	E
				
Top Frame 1pc	Bottom Frame 1pc	Top Glass 1pc	Bottom Glass 1 pc	Acrylic Rod 4pcs


Hardware list:

a	b	c
		
Bolt 8 pc	Bumper Pad 8 pc	Allen Key 1pc


Step1. Assemble the Acrylic Rod(E) to the bottom Fram(B) as shown.




Step2. Assemble the Top Frame(A) to the Acrylic Rod(E) as shown.



Step 3. Put the Rubber Pads(b) and the Top Glass(C)and Bottom Glass(D) on the iron base.



Step4. Assembly is complete.



Care Instruction

- Avoid placing your furniture direct from sunlight.
- Keep your furniture away from any solvents such as nail polish remover, alcohol, paint thinner...etc.as these can damage the finish.
- For metal furniture it must be dusted regularly and occasionally wiping with soft damp cloth.
- For tougher dirt, wash with hot and soapy water then rinse and let dry and wipe with dry soft cloth afterwards.
- For metal furniture never use abrasive, strong detergent or any rinse powder as they may contain alkali that damage the finish,
- Use mild detergent and water to clean, Do not use harsh abrasive,