


## Assembly Instructions Item: T1803 Entertainment Center

ALL DRAWER PULLS HAVE BEEN FIXED INSIDE OF DRAWER TO PROTECT THE FURNITURE DURING SHIPMENT

USE FOLLOWING STEPS TO INSTALL THE HARDWARE



## FRONT PANEL OF DRAWER

- 1- Use a screwdriver to remove the drawer pulls from the drawer first. IMPORTANT:Don't throw any of the part!!!
- 2- Insert"A" screw bolt through predrilled hole from back side of drawer.
- 3- Place "C"rubber washer to the glass surface of the drawer front.
- 4- Apply "B"drawer pull to the bolt.
  ATTENTION: DON'T USE ANY ELECTRIC OR MACHINE
  SCREWDRIVER.THIS WILL BREAK THE GLASS SURFACE!!!

5-Use a screwdriver by hand to turn "A" screw bolt, when resistance is evident, STOP! DO NOT OVER TIGHTEN!!!