

# ASSEMBLY INSTRUCTIONS — MODEL: FIONA / CRYSTAL DINING TABLE

# Please read instruction carefully

Remove all wrapping materials, staples, and packing straps from the carton. Refer to Part List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from being scratched.

CAUTIONS:1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

2) DO NOT OVER-TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.


3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.


### PART LIST

NO.	COMPONENT	QTY.
Pl	TABLE TOP	1
P2	MOUTING PLATE	1
P3	BASE	1

# HARDWARE LIST

NO.	DESCRIPTION		QTY
HI	JCBC SCREW M6 X 35mm	<u> </u>	14
H2	SPRING WASHER	@	14
НЗ	FLAT WASHER	0	14
H4	ALLEN KEY		1
Н5	LEG ADJUSTER GLIDER	<b>©</b>	.4








H4

НЗ

H1







# CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children and animals, dispose of plastic bags immediately

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted