

# ASSEMBLY INSTRUCTIONS MODEL: BELLE DINING CHAIR

#### Please read instruction carefully

Remove all wrapping materials, staples, and packing straps from the carton. Refer to Part List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from being scratched. CAUTIONS:1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

2) DO NOT OVER-TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.


### PART LIST (FOR 2 NOS. OF CHAIRS)


NO.	COMPONENT	QTY.
P1	CHAIR BACK	2
P2	CUSHION CHAIR SEAT	2
P3	FRONT LEG	4

## HARDWARE LIST (FOR 2 NOS. OF CHAIRS)

NO.	DESCRIPTI	ON	QTY 16
Hl	JCBC SCREW M6 X 80	0	
Ĥ2	JCBC SCREW M6 X 35	0	- 4
НЗ	SPRING WASHER	@	20
H4	FLAT WASHER	0	20
H5	ALLEN KEY		1
Н6	NAIL LEG	-0	8







#### CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children and animals, dispose of plastic bags immediately

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted