





Best Master Furniture™
The Imported Furniture Specialist

ITEM# JJ039



ASSEMBLY GUIDE

BOX LIST










E	SideRail	2PCS
F	Center Support bar	1PC



H	Footboard	1PCS
I	Small Slat	24PCS
J	Feet	2PCS
P	Metal Leg Support	2PCS
L	LONG SLAT	1PCS



HARDWARE PACKED LIST IN BOX

a	Allen Key ø5/16"	1PCS	b	Bolt ø5/16"*1.5"	12PCS	c			d	Flat Washer ø5/16"	16PCS
											
e	Spring Washer ø5/16"	16PCS	f	Bolt ø1/4"*1"	0 PCS	g	NUT ø5/16"	4PCS	h	Rails plastic sla	26PCS
											
i	Center plastic slat	13PCS	Wrench	Not provided		j	Allen Key 5mm		k	Bolt ø5/16"*2"	4PCS
											


MADE IN CHINA

QUEEN BED
ASSEMBLY INSTRUCTIONS

ITEM:JJ039

STEP1


Bolts to use for side rails, should already come pre-inserted on the HB. Place bolt (b), washers (e , d) and fasten to Headboard with preinstalled hardware, Repeat step 2 for Footboard. Do not tighten until step 3.



MADE IN CHINA


STEP 2

Attach siderail (E) to headboard (G) and footboard (H) using bolt (b) and allen key (a) as shown in diagram. Do not tighten bolts completely until assembly is completed.



STEP 3


Attach center support (F) to headboard (G) by using bolt (b) through washers (e , d) as shown in diagram.



MADE IN CHINA


STEP 4

Attach leg support (K) to center support bar (F) by using bolt (k), washers (e, d), nut (g), and tighten the nut (g) by wrench.



STEP 5


Insert center plastic slot (i) into holes on center support bar (F). Press firmly into place as shown in diagram. Attach rail plastic slat (h) using same procedure.



MADE IN CHINA


STEP 6

Insert small slat (I) into plastic slats (h, i) as shown in diagram. Attach long slat (L) to Siderail (E) with bolt f as shown.



STEP 7

Assembly is complete.



MADE IN CHINA